



Ford 6.7 Powerstroke load Instructions

- 1) Connect supplied device (SCT BDX) to vehicles OBDII port and turn the ignition to ON (do not start the vehicle).
- 2) **Select Program Vehicle and load the tune in the following order**
 - a. Select the tune file "Load First" and load it following the on-screen prompts
 - b. Directly after the above file is loaded, proceed to load the tun power level.
 - i. EX: "80HP wTCM, SOTF, etc"
- 3) Start the truck. Tune is complete

Note: Please allow 100-150 Miles for the trans to relearn. You will only need to load the tune "Load First" once, and not every time you are switching tune.

Same Day Tuning

855-553-7474

