

# ***2011-16 LML Duramax EZ Connect SOFT***

## **Installing Ez Connect LML SOFT**

- 1) After the Switch on the fly (SOTF) calibration has been installed connect the LML Ez Connect switch to EGT #1 sensor which is located on the back of the turbocharger on the opposite side as the NOX sensor as pictured below. Connector will just snap on. Route the Switch side inside the cab through the firewall. When connecting the red quick connect bullet connectors, it does NOT matter which side goes to which



